

**MT-16T
ELECTRONIC
KEY TELEPHONE
USER GUIDE**

 **MACROTEL**

MACROTEL INTERNATIONAL CORPORATION

MacroTel International Corporation reserves the right, without prior notice, to revise this information publication for any reason, including, but not limited to, utilization of new advances in the state of technical arts or to simply change the design of this document.

Further, MacroTel International Corporation also reserves the right, without prior notice, to make such changes in equipment design or components as engineering or manufacturing methods may warrant.

Under no circumstances will the retail customer or any user or dealer or other person be entitled to any direct, special, indirect, consequential or exemplary damages, for breach of contract, tort, or otherwise. Under no circumstances will any such person be entitled to any sum greater than the purchase price paid to MacroTel for the item of equipment that is malfunctioning.



MACROTEL INTERNATIONAL CORPORATION
6001 Park of Commerce Boulevard
Boca Raton, FL 33487

© Copyright 1994, MacroTel International Corporation, All Rights Reserved Worldwide. This publication has been provided pursuant to an agreement containing restrictions on its use. This publication is also protected by federal copyright laws. No part of this publication may be copied or distributed, transmitted, stored in a retrieval system, or translated into any human or computer language, in any form or by any means, electronic, mechanical, magnetic, manual or otherwise, or disclosed to third parties without express written permission of MacroTel International Corporation, 6001 Park of Commerce Boulevard, Boca Raton, Florida 33487.

MacroTel International Corporation reserves the right to revise this manual and to make changes from time to time in the content hereof without obligation to notify any person or organization of such revision or changes. Due to the ever-changing nature of the high tech environment as well as the complexity of the product, MacroTel International Corporation assumes no responsibility for any errors or omissions that may appear in this publication.

INDEX

ANSWERING A CALL	5
ACCOUNT CODE	7
APPOINTMENT REMINDER	13
ATTENDANT FEATURES & PROGRAMMING	15
AUTO ANSWER	7
BACKGROUND MUSIC	11
BOSS/SECRETARY	12
CALLBACK	6
CALL FORWARD	10
CALL OFFERING	9
CALL PICK UP	10
COMMON AUDIBLE RING	17
CONFERENCE	9
DESCRIPTION OF KEYS	3
DIRECT RETRY	7
DISA	17
DO NOT DISTURB	11
DOORPHONE	14
EXECUTIVE PRIORITY	9
FLASH	7
GROUP LISTENING	9
HUNT GROUP	5
HOLD	6
INTERCOM OFF-HOOK SIGNALING	6
INTRODUCTION	1
KEY PROGRAMMING	15
LED INDICATIONS	1
MESSAGE WAITING	12
MUTE	11
MT-16T TELEPHONE ILLUSTRATIONS	2
PAGING	10
PERSONAL SPEED DIAL DIRECTORY	19
PLACING A CALL	5
PRIME LINE PRESELECT	14
PRIVACY RELEASE	13
PULSE TO TONE	8
REDIAL	7
RETRIEVING CAMPED-ON CALL	9
RINGING LINE PREFERENCE	8
SPEED DIAL	13
STATION NAME	14
STATUS MESSAGE DISPLAY	12
SYSTEM SPEED DIAL DIRECTORY	19
TIMER	11
TOLL RESTRICTION OVERRIDE	12
TRANSFER	8

INTRODUCTION


Your key telephone is the latest in high technology telecommunications equipment. Although your telephone is extremely sophisticated, it is very easy to operate.

Please take just a few minutes to read the description of the keys on your phone before beginning to read the User Guide.

LED INDICATIONS

{MSG} light flashing = Message Indication	pg 12 & 3
[ALM/SD] lit solid = Appointment Reminder	pg 13 & 4
[SPK] key rapid flash = Call Forward	pg 10 & 3
[MUTE/DND] flashes on attendant = Night Mode	pg 16 & 3
[PAGE] key flashes = Common Audible Ring	pg 17 & 4
[SPK] key slow flash = Auto Answer off	pg 7 & 3

MT-16T DISPLAY TELEPHONE



DESCRIPTION OF KEYS AND COMPONENTS

Outside Line - You can select the outside line you want to use by pressing one of these keys.

Liquid Crystal Display [LCD] - The LCD is an optional unit that can be added to your telephone. It displays date, time, and call information for you.

Personal Speed Dial Key / Direct Station Selector [DSS] - This key has two functions. You can store up to 16 frequently called numbers. One associated with each of your 16 personal speed dial keys. The other function this key performs is DSS. A DSS is used to call another station on the intercom. It's easy, just lift your handset and press the key that's labeled with the station number you wish to speak with.

Conference - This key is labeled [CONF]. It allows you to join outside lines together for a conference call or allow other stations in your phone system to enter into a conference call. Up to five parties can be conferenced together.

Page - If your system has a loudspeaker, like in a warehouse area, you can make a [PAGE] by pressing this key.

Dial Pad - The dial pad is used to dial telephone numbers. It's also used for entering programming data.

Program - One of the functions of the [#] key on your dial pad is to activate your station programming mode.

Hold - Place a call on hold by pressing the [HOLD] key.

Microphone - The small opening on the lower right hand side of the telephone is where the speakerphone microphone is located.

Speaker - You can turn your speakerphone on and off with the [SPK] key.

Speaker Volume Control - When using the speakerphone you can adjust the speaker volume.

Last Number Redial - With the [RD] key you can redial the last number you called. It's also used to save a frequently called number. Think of it as an additional personal speed dial.

Mute/Do-Not-Disturb - This key has two functions. If you are using your speakerphone you can temporarily turn off your microphone, [MUTE], so that you can confer with someone else and the outside party can't hear you. If you are in a meeting and do not want to be disturbed, just press the key and no one will be able to interrupt you with an intercom call.


Handset - If you want a private conversation, just lift your handset to speak and your speakerphone is automatically turned off.

Message Key - The [MSG] key allows you to alert another station in the system that you would like them to call you back. It also allows you to call back other stations that have alerted you.

Appointment Reminder/Speed Dial - The [ALM/SD] key has two functions, it gives you the capability of programming your phone to notify you, with a tone and display, of an important engagement. The [ALM/SD] key is also used to access your personal and system speed dial numbers.

Timer - Press the [TIMER] key to start and stop the stopwatch timer.

MT-16T NON-DISPLAY TELEPHONE



Auto Redial - Press this key to activate the automatic redial feature. While the system attempts to place your call, you can concentrate on other matters.*

Internal Page - This is a page key for internal page.

Doorphone - The doorphone key is used to answer doorphone calls and unlock doors.

Auto Answer - This key turns auto answer mode on and off.*

Boss/Secretary - The [BOSS/SECRETARY] key is a hotline from boss to secretary.

Attendant - Reach the attendant with the press of a key.

Common Audible Ringing - This key allows the operator to place the phone system into common audible ring mode. It is the second round button from the left on the operator telephone.**

CALLING A HUNT GROUP***

- Lift handset, then dial pilot number [*1], [*2], or [*3]; or Press group key (speaker turns on automatically.)

PLACING AN INTERCOM CALL

- Lift handset, then press [DSS] key of desired station or Press [DSS] key of desired station (speaker turns on automatically).
- Speak into handset to converse or use speakerphone.
→ You may call the station directly by dialing [21-36] for stations [01-16] respectively.

PLACING AN OUTSIDE CALL

- Lift handset, then press outside line key or Press outside line key (speaker turns on automatically) or Lift handset and dial [9] to automatically select an available line (if programmed) or Lift handset or Press SPK key, then dial 8 followed by outside line number 1-8.
- Dial number.
- When outside party answers, converse on the handset or speakerphone.
- Dial '7' is also available.**

ANSWERING AN INTERCOM CALL

Auto Answer Mode

- After hearing tone burst, you may begin speaking into speakerphone (Not private) or After hearing tone burst, lift handset to converse (Privacy).

Ringing Mode

- When your telephone begins ringing, press the [SPK] key and begin speaking (Not private) or When your telephone begins ringing, lift handset to converse (Privacy).

ANSWERING AN OUTSIDE CALL

(Ringing phone)

- Lift handset or Press [SPK] key.
Line ringing on your phone is automatically connected.

(Non-ringing phone)

- Lift handset, then press flashing green outside line key or Press flashing green outside line key (speaker turns on automatically) or Lift handset, then dial 11.
The most recent incoming call will be answered.

ATTENDANT CALL

- Lift handset and dial "0", or with handset in cradle, dial "0" (speaker turns on automatically), or Press [Attendant] key.

PLACING OUTSIDE LINE OR INTERCOM ON HOLD

Universal Hold

- Press [HOLD] key.

(Any station can retrieve outside line from [HOLD]).

- To retrieve, press flashing outside line or [DSS] key.

→ DSS is exclusive hold.

Exclusive Hold

- Press [HOLD] key twice.
(Only station that placed call on hold can retrieve).
- To retrieve, press flashing outside line or Press DSS key or Lift the handset, then dial 8 followed by outside line number 1~8.

→ Calls not retrieved within a preset amount of time will recall the originating station.

→ Calls on exclusive hold, that are not retrieved, will become universal hold upon recalling to the operator.**

CONSULTATION HOLD

- While on an outside line, press [DSS] key for desired party.
- Inside party answers, consult.
- Inside party hangs up.
Connection to outside party is reestablished.

HOLD RECALL

- When an outside line or [DSS] call has remained on hold for an extended period of time, you will be reminded with a recall tone.
 - While telephone is recalling, lift handset or press [SPK] key.
- Outside line recalls not answered by the originating station within preset time will recall the attendant station.**

INTERCOM CALLBACK

- Place an intercom call to a busy station.
- Wait five seconds for confirmation tone.
([MSG] light on your phone flashes).
- Hang up.
- When called station hangs up, your phone will ring.
- Lift handset or press [SPK] key,
and called station's phone will ring.

OUTSIDE LINE CALLBACK

- Select busy outside line, wait five seconds for confirmation tone. [MSG] light flashes.
- Hang up.
- When line becomes free, your phone will ring.
- Lift handset and begin dialing.

INTERCOM OFF-HOOK SIGNALING

To Set

- With handset in cradle, dial [#] .
- Dial [12].

- Dial [1] to enable or [0] to disable.

- Dial [#].

• While on a call, this feature enables or disables an alert tone to your station when called by another station on intercom.

FLASH

- While connected to outside line, press line key again.
Disconnects call and gives you the line back to make another call.

LAST NUMBER REDIAL

- Press [RD] key.

To Save

- After dialing number, press [RD] key before hanging up.

To Redial

- Press [4].
Line is selected automatically and saved number is dialed.

AUTOMATIC REDIAL

If the outside telephone number you dial is busy.

- While listening to busy signal, press the [AUTO REDIAL] key.
- Hang up.
• The phone will attempt to place the call again for you,
up to three times at 45 second intervals.
• Programmable from 1~99 retries.**
• LED on [RD] key flashes to indicate this feature is active.

AUTO ANSWER (Intercom Only)

To Turn On and Off

- With handset in cradle, dial [#].
 - Dial [10].
 - Dial [1] for auto answer or [0] for ringing mode.
 - Dial [#] key or press [Auto Answer] key.
- [SPK] key flashes when in ringing mode.
→ Programmable key: Auto Answer.*

ACCOUNT CODE ***

While speaking to outside party

- Depress [ACCOUNT] key.
 - Dial account code up to 7 digits including [*] and [#].
 - Depress [ACCOUNT] key.
- Duration timer must appear on LCD before account code can be entered.

DIRECT RETRY

- If you encounter the following on an intercom call:
Called party hangs up Do Not Disturb Busy
No answer Invalid Station
- You may place another intercom call without hanging up.

RINGING LINE PREFERENCE***

- With handset in cradle dial [#] .
 - Dial [17].
 - Dial [1] to enable or [0] to disable.
 - Dial [#].
- This feature allows the user the choice between pressing the line key or not pressing, to answer a call that is ringing at the telephone.

PULSE TO TONE CHANGEOVER ON OUTSIDE CALL

- When on outside line, dial [#] on the key pad to change from pulse to touch tone dialing.

TRANSFER

Unscreened Transfer

- While on an outside call, press [DSS] key of desired station (outside party automatically put on hold).
- Hang up.
 - If not busy, outside line rings station.
 - If no answer, outside line recalls you.
 - If busy, outside line CAMPS ON to station and tone alerts called party. If called station doesn't answer after an extended period of time, the line recalls you.
- While still in transfer mode, before hanging up, pressing same [DSS] key will disengage station connection and return caller to you.

Screened Transfer

- While on an outside call, press [DSS] key of desired station (outside line automatically put on hold).
- Await reply. If accepted, hang up. If not accepted, when called station hangs up, outside line will be reconnected automatically.
- While still speaking to station, if second outside line rings, pressing second outside line completes transfer.**

or

- Place outside line on hold by pressing hold key.
- Call desired station on intercom.
- Announce call and outside line number.
- Hang up.
- If accepted, called station presses outside line key. If not accepted, originating party retrieves call.

Transfer Via Internal Page

- While talking to outside party, press your own [DSS] key.
- Dial Zone (0,1,2 or 3) ***
- Announce call and outside line number.
- Hang up.
- Paged party presses outside line key.

Transfer Via External Page

- While talking to outside party, press page key.
- Announce call and outside line number.
- Hang up.
- Paged party presses outside line key.

RETRIEVING CAMPED-ON CALL

- Complete existing call and hang up. Your phone will ring. Lift handset or Press [SPK] key
- or
- Put existing call on hold, and hang up. Your phone will ring. Lift handset or press [SPK] key.
- Camped on tone is heard once every 10-99 seconds until retrieved.**

CALL OFFERING

To interrupt a busy extension.

- Depress busy intercom [DSS] key.
- After receiving busy tone, depress again. (Your DSS will flicker on called person's phone.)
- Stay on line, you will hear hold music until you are connected.

→ Additional depressions of DSS key will send additional interruption tones.**

To receive a call while busy on intercom or outside line.

- After hearing the interruption tone, depress the flickering DSS key. Your call goes on exclusive hold and you are connected to the caller.

EXECUTIVE PRIORITY (If Programmed)

- Press busy [DSS] key of station you wish to override.
- Dial 5.
- Override status is displayed on LCD. If Conference, Transfer, Hold or Forward features are engaged, override is not permitted.

GROUP LISTENING ***

While on an outside call:

- Press group listening key.
- Outside party's voice can be heard by others in the room from the speaker.
- Feature automatically cancels when the phone is hung up.

CONFERENCE

- Establish call (outside line or intercom).
- Press [CONF] key.
- Establish another call (for additional parties, repeat the last two steps).
- To join conference, press [CONF] key twice.

TO RELEASE A PARTY FROM CONFERENCE

- Establish conference.
- Press [CONF] key.
- Press the outside party's line or [DSS] key that you want to exclude.
- Press [CONF] key to return to conference.

UNSUPERVISED CONFERENCE

- Establish conference.
- Press [CONF] key, then your own [DSS] key to leave the conference.
- (To rejoin conference, lift handset and then press [CONF] key.)
- During unsupervised conference, a warning tone is heard 15 seconds before the system disconnects the conference. Press [*] to override disconnection. Press [#] to disconnect call at any time.***

CALL FORWARD

To Set

- With handset in cradle, dial [#].
- Dial [11].
- Dial [1] for Intercom **, [2] for Outside Line, or [3] for Both.
- Press [DSS] key of transfer location.
- Dial [#] (Speaker key will flicker).

To Cancel

- With handset in cradle, dial [#].
- Dial [11]
- Press your own [DSS] key.
- Dial [#].

→ Call forward applies to intercom and transferred outside lines.

→ Call forward applies to intercom, outside lines, or both.**

CALL PICK UP

Intercom Call Only

- Lift handset or press [SPK] key, then press ringing [DSS] key.

Intercom and Outside Lines

- Lift handset or press [SPK] key, dial 11.

→ Also answers in common audible ringing.**

• Also answers DISA calls.***

PAGING

Internal

- Lift handset.
- Press your own [DSS] key or internal page key.
- Dial zone (0,1,2 or 3).***
- Make announcement.

→ Programmable key: Internal page.

External

- Lift handset.
- Press external page key.
- Make announcement.

• Programmable key: External page.

→ DTMF tones can be sent over page circuit.***

→ 0 = All call.

MEET ME PAGE

- Press own [DSS] key.
 - Dial Zone (0,1,2 or 3).***
 - Instruct paged party to dial 12.
 - Press own [DSS] key again and stay on line.
 - Paged party lifts handset, then dials 12 to speak with you.
- Programmable key: Internal page.

MEET ME PAGE/CALL PARK ***

While speaking to outside caller:

- Depress own [DSS] or page key.
- Dial Zone (0,1,2 or 3), make announcement. (Internal Page)
- Depress own [DSS] or page key, and wait off-hook.
- Paged party dials [12].
- Tell paged party what line call is on.
- Hang up.

→ If after step 3 the paging party hangs up, the paged party will be connected directly to the outside party when [12] is dialed.

DO NOT DISTURB

- With handset in cradle, press [DND] key.
- [DND] key lights up.

→ Disables intercom calls to your station. Not available on Attendant station.

BACKGROUND MUSIC (If Enabled)

- With handset in cradle, press the [HOLD] key. (Music is heard).
- Press [HOLD] key a second time and music is turned off.

→ Music is automatically turned off when telephone is in use.

MUTE

- While on speakerphone, press [MUTE] key.
- Microphone is turned off.

TIMER

- With handset in cradle, press timer key to start.
- Press timer key to stop.
- Lift handset to restore display.

→ Timer key must be programmed on your phone.

While Talking

- When you place an outside call, the timer starts automatically.
- Press the timer key to display dialed number.
- Press the timer key for the total elapsed time.
- Additional depressions of timer key repeat display of dialed number and elapsed time.

AUTOMATIC TIMER

To Disable or Enable

- With handset in cradle, dial [#] .
- Dial [15].
- Dial [0] to disable or [1] to enable.
Dial [#] .

TOLL RESTRICTION OVERRIDE

(Traveling Class of Service)

- Dial [#].
 - Dial [00].
 - Enter password _ _ _ _ _ .
 - Dial [#].
- Must place phone call within 60 seconds.

MESSAGE WAITING

To Leave a Message

- Call a station.
- Press [MSG] key.
- Hang up.

To Retrieve a Message

- Lift handset or press [SPK] key.
 - Press flashing [MSG] key (station that left you message will be called automatically).
- Message indication clears if other station answers you.

To Review Messages

- With handset in cradle, press flashing [MSG] key.
 - Stations that have left messages will be listed.
- Display phone only.

To Cancel Messages

- With handset in cradle, press flashing [MSG] key.
Press [DSS] key of station that left you the message.

STATUS MESSAGE DISPLAY

To Set

- With handset in cradle press [DND].
- Dial [*] or [0] to advance or reverse messages.
- Dial [#] after selection is complete.

To Cancel

- With handset in cradle, press [DND] key.

BOSS/SECRETARY (If Programmed)

- Boss and secretary can override each other [DND] by pressing [BOSS/SECRETARY] key.
- If boss phone is in [DND], all intercom calls to boss will ring secretary's phone.

APPOINTMENT REMINDER

To Set

- With handset in cradle, press [ALM/SD] key twice.
 - Enter four digit time (military time).
 - Depress [ALM/SD] (key will light solid).
- Your phone will ring at set time.

To Cancel

- Press the [ALM/SD] key twice, then press the [HOLD] key.

PERSONAL SPEED DIAL

To Store or Change:

- With handset in cradle, press [ALM/SD] key.
- Press specific [DSS] key to store number.
- Enter phone number [HOLD] KEY = 3 SECOND PAUSE).
- Press [ALM/SD] key to finish.

To Use

- Select outside line.
- Press [ALM/SD] key.
- Press desired [DSS] key.

To Erase

- With handset in cradle, press [ALM/SD] key.
 - Press [DSS] key of number to be erased.
 - Press [HOLD] key.
- Personal speed dial bins 1 and 2 will not display programmed numbers for privacy.

SYSTEM SPEED DIAL

To Use:

- Select outside line.
- Press [ALM/SD] button.
- Dial BIN number 10~99.

CHAIN DIALING SPEED DIAL

- Select personal or system speed dial number.
 - Dial additional digits manually or Press [ALM/SD] key again.
 - Press desired [DSS] key or system bin number.
- You may chain as many speed dial numbers together as required.

PRIVACY RELEASE (If programmed)

You may allow other users to enter your conversation.

- While talking on an outside line, press the outside line key a second time.
 - Privacy release released, other users can pick up the line.
 - When the other party has joined the conversation, you can prevent other users from entering the line by pressing the outside line key again.
- Mute key activates on users who join the conversation in speakerphone mode.

PRIME LINE PRESELECT

- With handset in cradle, dial [#] .
 - Dial [13].
 - Dial [1] to enable outside line or [0] for ICM.
 - Dial [#].
- This feature gives the user a choice between ICM or outside line. If outside line is allowed, then every time the user lifts the handset, an outside line will be automatically selected instead of an ICM line.
- If C.O. is enabled, Meet Me Answer is disabled.

STATION NAME

Users can program their names to appear on the LCD.

- With handset in cradle, dial [#] .
- Dial [14].
- Press a key on the dial pad followed by outside line key 1,2 or 3; corresponding first, second, or third letter.

Example: To program "SUE"

Since "S" appears as the third letter on the seven key, press [7] and line key [3], for "U" press [8] and line key [2], for "E" press [3] and line key [2].

or (With software** use the following step instead):

Each subsequent depression of a key on the dial pad sets one of the 3 letters or number printed on the key.**

Example: 0 key = : . ! 0
1 key = Q Z * 1
2 key = A B C 2

- After entering your name dial [#].
- [HOLD] key = Erase.
- [MSG] key = Space.
- [ALM/SD] = Backspace
- [DSS] = Message location [DSS-1~DSS-10]
- [*] = Advance to next character.
- Attendant can program other users' names by pressing [DSS] key before the third step.

ANSWERING A DOORPHONE

(Ringing Phone)

- Pick up handset or press speaker [SPK] key.
- Connection is complete.

(Non-ringing phone)

- Press [DOOR] key.
- Connection is complete.

TO OPEN DOOR

- Press [DOOR] key twice.
 - Relay operates to open door.
- Door remains unlocked for predetermined amount of time or until user hangs up.**

TO CALL DOORPHONE

- Press [DOOR] key 1 time.
- Connection is completed.

ASSIGNING FEATURES TO 4 ROUND KEYS ***

- Dial [#].
- Dial [18].
- Depress round button to be programmed.
- Dial selected code from table to change function of round button.

Codes:

- | | |
|----------------------|--------------------------|
| (33) TIMER | (34) AUTO ANSWER |
| (35) AUTO REDIAL | (36) BOSS/SECRETARY |
| (37) INTERNAL PAGE | (38) ATTENDANT |
| (39) DOOR PHONE | (40) COMMON AUDIBLE RING |
| (41) GROUP LISTENING | (42) ACCOUNT CODE |
| (43) GROUP 1 | (44) GROUP 2 |
| (45) GROUP 3 | |

HEADSET OPERATION

To Turn On/Off:

- Dial [#].
- Dial [16].
- Dial [1] for On or [0] for Off
- Dial [#].

ENABLING USER PROGRAMMING ***

- While handset is in cradle, dial [#].
- Dial [0].
- Dial User password _ _ _ _ _.
- Dial [1] then [#].

TIME AND DATE (Attendant Feature)

Enable User Programming, then:

- Dial [#].
- Dial [55].
- Input new data:

YY = Last 2 digits of year	1 = Monday
MM = Month (01~12)	2 = Tuesday
DD = Day (01~31)	3 = Wednesday
W = Weekday	4 = Thursday
HH = Hour (24-hour mode)	5 = Friday
MM = Minutes (00~59)	6 = Saturday
	7 = Sunday
- Dial [#].

→ User program enable not required.*

OPTIONAL CLASS OF SERVICE (Attendant Feature)

- Dial [#].
- Dial [26].

- Enter User password _____.
 - Enter one of the following numbers to set nighttime toll restriction:
 - 0 = Same as daytime toll restriction.
 - 1 = All stations class B.
 - 2 = All stations class C.
 - 3 = All stations class D.
 - 4 = All stations class E.
 - (If Exception status changes, Dial [1] for exception or Dial [0] for no exception.**)
 - Dial [#].
- When attendant activates this feature, all telephones will follow class selected. The attendant must repeat the procedure to return to normal day toll restriction (Enter [0]).
- The fifth step is only required one time.**
- Exempt phones don't follow class selected.

SYSTEM SPEED DIAL (Attendant Feature)

Enable User Programming, then:

To Change or Store:

- Press [ALM/SD] key.
- Dial in BIN number [10~99].
- Dial phone number([HOLD] Key = 3 SECOND PAUSE).
- Press [ALM/SD] key.

To Erase

- Press [ALM/SD] key.
- Dial BIN number to erase.
- Press [HOLD] key.

→ System speed dial bins [90~98] will not display programmed numbers for privacy.

→ Speed dial bins [90~98] require enabling system programming.*

NIGHT TRANSFER (Attendant Feature)

- Press [MUTE/DND] key on Attendant phone.
- [MUTE/DND] lamp flashes, system is in night mode.

EXTERNAL CALL FORWARDING (Attendant Feature)

Enable User Programming, then:

To Program External Call Forwarding:

- With handset in cradle, dial [#].
- Dial [45].
- Dial [0] (Deny) or [1] (Allow) for each outside line to be forwarded.
- Dial [#].
- Press [ALM/SD] key.
- Dial [99] (System speed dial bin 99).

- Dial [09] followed by telephone number that you want to forward to; *or*
Dial [8] followed by outgoing line number [1-8], followed by the telephone number that you want to forward to.

- Press [ALM/SD] key.

→ [09] before telephone number will select a random outgoing line. [81~88] will select a specific outgoing line.

Example: 82 = Line 2
87 = Line 7

→ Steps must be performed only if changes are needed.

To Turn On/Off

- Dial [#].
- Dial [27].
- Enter User Password _____.
- Enter [1] for On or [0] for Off
- Dial [#].

→ During external call forward, a warning tone is heard 15 seconds before the system disconnects the call. Press[*] to override disconnection. Press[#] to disconnect call at any time.**

COMMON AUDIBLE RINGING (Attendant Feature)**

To Turn On/Off:

- Dial [#].
- Dial [28].
- Enter User Password _____.
- Enter [1] for On or [0] for Off
- Dial [#].

→ Programmable key: Common Audible Ringing.

CALLING DISA FACTS TO KNOW**

- Calling an internal station requires no password.
- If called station is busy, no answer, DND, or invalid extension, a [*] will return internal dial tone.
- If station answers, talk time is not monitored.
- If C.O. access is required, dial [9] or [81-88], wait for silence, and then enter password.
- If C.O. is accessed, talk time is monitored and a warning is heard before disconnection.
Press [*] for more talk time.
Press [*] before warning tone and internal dial tone is returned.
- Pressing [#] at any time disconnects DISA.

MT-360

The MT-360 is totally digital, right down to the desktop. From a system-wide advantage, the MT-360 delivers least cost routing, forced account codes, DISA, toll restriction, remote programming, and battery reversal detection.

MT-16H Hybrid System

This state-of-the-art compact hybrid provides thrifty single-line capabilities. From a 4x8 configuration with two stations available for single-line use, the MT-16H can be upgraded to eight lines and sixteen stations.

MT-308 Plus KSU-less

This KSUless key system is highly recommended for small businesses and home offices, supporting up to three lines. The MT-308 can also operate as an advanced feature telephone behind a PABX or Centrex system. Now that's flexibility!

MT-2001 Single-line

The MT-2001 Series are affordable, functional single-line phones. The MT-2001/S Standard Telephone offers all the basic necessities. The MT-2001/X Executive Speakerphone includes handset & speaker volume control.

MTH-32/128

The MTH-32 is highly evolved and grows from an 8x24 configuration all the way up to 128 ports. The system is right on the mark for today's telecommunications needs.

MVX

Fully-featured Automated Attendant/Voice Mail system. Offers many conveniences and also enhances productivity at an incredibly low price. Compatible with most telephone systems, the MVX accommodates virtually any application.

P/N:2609996

September 1994

Rev 3.4

Software Level MV0 MV1* MV2** MV3***

